

# Installation Instruction

SET-12060B

SET-24060B

SET-24096B



CLASS 2  
TYPE HL  
SELV



- \* Read instruction completely before installation.
- \* Turn off electricity before wiring.
- \* Only qualified personal should install the unit.
- \* Installation must comply with the NEC
- \* Ensure the unit has input, output voltage and output wattage proper for your application.

## Mounting

The LED driver must be mounted in at least 5" of a free flow air space for proper ventilation.

The LED driver must never be mounted next to or above heat radiated objects.

The Maximum ambient temperature should not exceed 50 deg. C (110 deg. F).

Suitable for dry,damp and wet location, IP44.

## Input Connection

Bring your line and neutral wires and econnect them to the driver's Black (live) and white (neutral) power supply leads.

## Output Connection

Bring your lights wires and connect to the driver's lead wires, V+ to Red, V- to Black.

Make sure all your connection are tight.

## Wiring Diagram

